

# 7

## B FRAME

*Drop in*

Drop in B frame typically used for a rough cut opening since the flange provides a crisp, clean, finished appearance.

